



### FC Street Version Polyurethane Motor Mounts



**Mount Installed**

The small bushing should be mounted under the sub-frame (beneath the car), there should be about a 3/8" of bolt sticking out of the driver's side, if you installed the bolts from the top. The passenger side should be around 1/8" protrusion due to the aluminum bracket thickness. The small bushing should be slightly compressed but not crushed flat.

Please contact [tech@banzai-racing.com](mailto:tech@banzai-racing.com) with enquiries